

burco[®] **REDI HEAT**

Instructions to replace a factory installed heating element

*Professional installation or electrical consultation is recommended.

#3801 5-7/8" x 3-3/16"

#3804 9-1/2" x 5-1/2"

#3805 12-1/2" x 6-1/2"

NOTE: Burco REDI HEAT should be used with a new Redi-Cuts[®] side view mirror. A 12v power supply is required. #3804/#3805 can be trimmed parallel to the terminals. Do not trim #3801. Trimming of #3801 will cause permanent damage heating element.

Clean Redi-Cuts side view mirror with Window Glo[™] or a comparable glass cleaner and allow to dry. Peel off the Redi heat adhesive backing. Apply to back of Redi-Cuts side view mirror.

Test fit first! Carefully position terminals with the existing terminal opening in the backing plate. Make sure the terminals line up with the holes. (do not allow terminals to touch one another as this may short out the unit.) You may have to drill new holes in the backing plate through which the terminals will fit.

Apply silicone or urethane to the backing plate and install mirror. As a precaution, you may want to tape the mirror to the backing plate until silicone or urethane cures.

Modifying a non-heated application may require supplemental wiring and modifications to the backing plate.

DISCLAIMER: Burco is not responsible for any damage incurred to vehicles and will not provide electrical consultation of any sort.